


How to tile onto...

Cement Screed or Concrete with Undertile Heating



1. Ensure the cement screed surface or concrete floor is fully cured, flat, clean and free of grease before commencing.
2. To improve heating performance, we recommend using a minimum of 10mm Nicobond Tile Backer Board as an insulation layer. Adhere the tile backer board directly onto the concrete/sand:cement screed using the recommended adhesive and allow to dry.
3. Lay out the undertile heating wire or mat and tape into position.
4. Apply a layer of the recommended adhesive to cover the wires and boards and provide a suitable adhesive layer 3-6mm thick in which to bed the tiles using a 10mm Nicobond Notched Trowel.
5. Fill the joints between tiles with the recommended grout using a float grouter. Remove surplus grout from the surface with a sponge and smooth the joints with a rounded stick to achieve an even better finish.

*Allow at least 6 weeks for structural concrete floors to cure and further 3 weeks for subsequently applied screed. In the event that a rapid setting cement replacement is used the drying time of screed will be greatly reduced.

*The tile adhesive must be fully dry (minimum 7 days) before the heating is switched on.

* Note that an Undertile Heating Mat system is also available for professional use. Refer to Nicobond Tiling Products The Directory for information.

* The recommended 10mm Tile Backer Board is the minimum to be used. Improved insulation will result from the use of thicker boards.

Recommended Tile Adhesives



Nicobond Rapidflex



Nicobond Large Format Floor Tile Adhesive



Nicobond Single Part Flexible Adhesive



Nicobond Flexible Grout Plus



Nicobond Starlike Extreme Performance Grout

Recommended Tile Grout

Featured Products



Nicobond Undertile Heating



Manufacturing Tiling Solutions Since 1958

N&C Tiles & Bathrooms Trade Counters & Showrooms

1A - 1B Alexander Place
Lower Park Road, New Southgate
London N11 1ST
Tel: 020 8361 6050
Fax: 020 8361 4757

8 Ascent Park, Edinburgh Way
Harlow, Essex CM20 2HW
Tel: 01279 621980
Fax: 01279 621981

14 Meridian Trading Estate
Bugsby Way, Charlton
London SE7 7SJ
Tel: 020 8269 5960
Fax: 020 8269 5961

1 Cliffside Trade Park, Motherwell Way
Lakeside, West Thurrock
Essex RM20 3XD
Tel: 01708 680180
Fax: 01708 680181

16 Arlington Business Park
Whittle Way, **Stevenage**
Hertfordshire SG1 2BD
Tel: 01438 315400
Fax: 01438 740338

9 - 11 McDonalds Business Park
Maylands, **Hemel Hempstead**
Hertfordshire HP2 7EB
Tel: 0845 2606 025
Fax: 0845 2606 026

8D Pompey Centre, Fratton Way
Southsea, **Portsmouth PO4 8TA**
Tel: 02392 894599
Fax: 02392 894598

5 Tower Court, St David's Road
Swansea Enterprise Park
Swansea SA6 8QL
Tel: 01792 797337
Fax: 01792 774019

N&C Tiles & Bathrooms

Distribution Centres, Trade Counters & Showrooms

N&C Building Materials
41 - 51 Freshwater Road
Chadwell Heath
Romford, Essex RM8 1SP
Tel: 020 8586 4600
Fax: 020 8586 4646

C1 Cothill Trading Estate
Plympton, **Plymouth PL7 1SR**
Tel: 01752 339724
Fax: 01752 342746

B1 - B3 Sneyd Trading Estate
Sneyd Hill, Burslem
Stoke on Trent ST6 2PA
Tel: 01782 575727
Fax: 01782 575641

26 Colquhoun Avenue
Hillington, **Glasgow G52 4BN**
Tel: 0141 880 1200
Fax: 0141 880 1212

4 Waterloo Industrial Estate
Flanders Road, Hedge End
Southampton SO30 2QT
Tel: 01489 779700
Fax: 01489 779701

3 - 4 Cardiff Trade Park
Hadfield Road, **Cardiff CF11 8AQ**
Tel: 02920 390146
Fax: 02920 224356

2 City Park, Industrial Estate
Gelder Road, **Leeds LS12 6DR**
Tel: 0113 224 4630
Fax: 0113 224 4631

2 - 5 Albarn Close
Wyncolls Road, Severalls Park
Colchester, Essex CO4 9HY
Tel: 01206 844 161
Fax: 01206 845 878

